

## OPEN-HYTERA-OE-MASTER-ENGLISH

### Inhaltsverzeichnis

|                                                                       |   |
|-----------------------------------------------------------------------|---|
| 1 DMR WinMaster .....                                                 | 2 |
| 2 Parameters .....                                                    | 2 |
| 3 Server ID .....                                                     | 2 |
| 4 Timeslots / Talkgroups .....                                        | 2 |
| 5 LastHeard .....                                                     | 3 |
| 6 WinMaster Software .....                                            | 3 |
| 7 questions to the software and the WinMaster (OE-MASTER) in OE ..... | 4 |

---

## DMR WinMaster

---

by: Kurt OE1KBC oe1kbc@oevsv.at

On the ÖVSV server we installed the DMR OE-MASTER and you can use this master for testing issues.

You can connect with HYTERA RD985 or RD965 repeater with the IP Multi-Site Service license installed. The connection is done via the "Supermaster" service.

---

## Parameters

---

- Repeater Type: **IP Multi-Site Master**
- Jitter Buffer Length: **3**
- Authentication Key: **!! leave empty !!**
- IP Multi-site Networking UDP Port: **62015**
- P2P Firewall Open Time (sec): **6**
- IP Multi-Site Service: **checked**
- IP Multi-Site Service UDP Port: **62016**
- RDAC: **unchecked**
- Super Master Service: **checked**
- Super Master IP: **178.188.156.53**
- Super Master UDP Port: **62005**
- Super Master Multi-Site Service: **checked**
- Super Master Multi-Site UDP Port: **62006**

Please note: Use the UDP-Port "62006" only for the first tests and QSOs. After that you will get a fixed UDP-Port. This Port identify you repeater to routing- and informations systems.

Only with a fix UDP-Port you can use all the features in the WinMaster system. You can get this fix port form your WinMaster administrator. In Austria please contact me oe1kbc@oevsv.at

---

## Server ID

---

The HYTERA Repeaters to not give their ID to the network streams so i've to take this information from "Super Master Multi-Site UDP" Port.

Therefore, if you use the default UPD-Port 62006 no Server-ID can be calculated.

In coordination with Torsten DG1HT (for BMaster and SMaster) and OE1KBC (for WinMaster) we have the following possibilities:

Super Master Multi-Site UDP Port: **6FRLL**

6....fix

F....counting no. per region 1-4

R....Region 1-9 (in OE it is the state 1-9 in DL the first position of the postal code)

LL...country code - only the last both digits - (OE...2<32> DL...2<62> HB9...2<28> US...3<10>)

e.g.:

the second repeater in region 8 in OE **62832** or

the third repeater in postal region 4 in DL **63462** or

the forth repeater in region 7 in US**64710**

## Timeslots / Talkgroups

- local QSOs - the timeslot TS1 should be complete free for local QSOs. Please use TG9 to be compatible to the network issues.
- echo function- as a special we offer on TS1 a echo function. All you speak to TG9990 on TS1 will be responded after release of PTT.
- national QSOs - the timeslot TS2 with TG9 you can also use for local QSOs. With your country code (e.g. in OE TG232 or TG3 in USA) you can make nation wide QSOs
- international QSOs - with TG1 you are connected to all repeaters WW (US, EU, ...).

## LastHeard

via <http://87.106.3.249/dmr> you can see the list of the last heard QSOs.

## WinMaster Software

The WinMaster software is written with .NET C# and connect the repeaters to the network.. The parameters in the properties form give you the possibilities to assign talkgroups to your slots. So you can make your own local TGs and bind repeaters to a local DMR-Network. So it is possible to connect the local repeaters (connected to the same WinMaster) on TS1 with TG9. This is a local area connection.

If you run more than one WinMaster on the same SMaster (see routing concept) you can decided on every WinMaster how to connect this WinMasters together.

The three step model give us a dynamic structure for the future.

- WinMaster build the repeater connections and the network for the region
- SMaster combine the WinMaster regions to a nationwide network
- BMaster combine nations to continents

here a picture from the ÖVSV HYTERA-DMR OE-MASTER

| DMR+ MASTER 7.00 Linux 64Bit                                                                                         |                          |                 |            |                          |                 |              |                |             |       |         |           |             |              |          |       |
|----------------------------------------------------------------------------------------------------------------------|--------------------------|-----------------|------------|--------------------------|-----------------|--------------|----------------|-------------|-------|---------|-----------|-------------|--------------|----------|-------|
| HOME                                                                                                                 | Fri Mar 20 14:17:19 2015 |                 |            |                          |                 |              |                |             |       |         |           |             |              |          |       |
| SYSTEM                                                                                                               | DMR MASTER CONFIG        |                 |            |                          |                 |              |                |             |       |         |           |             |              |          |       |
| LOGFILE                                                                                                              |                          |                 |            |                          |                 |              |                |             |       |         |           |             |              |          |       |
| GPS-USER                                                                                                             | SYSOPEMAIL               | LocalMasterName | Locator_ID | TS1_INTERN               | TS1_EXTERN      | Ref Link     | Ref unlink     | sMaster_IP  |       |         |           |             |              |          |       |
|                                                                                                                      | oelkbe@chello.at         | OE-Vienna       | 2322       | 1,2,20,232               | 1,2,20,232      | User Link On | User Unlink On | 44.143.9.60 |       |         |           |             |              |          |       |
| DONGLE                                                                                                               | REPEATER ON MASTER       |                 |            |                          |                 |              |                |             |       |         |           |             |              |          |       |
| RPT-GEO                                                                                                              | DMR-ID                   | CALL            | LOGINTIME  | IP                       | TX              | QRG          | RX             | QRG         | SHIFT | START   | REF/RT    | Reflector   | TS1          | FIRMWARE | MODEL |
|                                                                                                                      | CONFIG                   | 232100          | OE1VAK     | Fri Mar 20 09:15:00 2015 | 44.143.9.70     | 62006        | 438.5000       | 430.9000    | -7.6  | 4191/15 | Link 4191 | 232 1 20    | DMR+ MB 0.95 | MBplus S |       |
| RPT-MAP                                                                                                              | CONFIG                   | 228391          | HE9BO      | Fri Mar 20 09:15:00 2015 | 213.202.59.75   | 62006        | 439.4125       | 431.8125    | -7.6  | 4180/15 | Link 4180 | 228 1 20    | A6.05.10.004 | RD985 M  |       |
|                                                                                                                      | CONFIG                   | 232108          | OE1VAK     | Fri Mar 20 09:15:00 2015 | 44.143.9.72     | 62006        | 438.6000       | 431.0000    | -7.6  | 4198/15 | Link 4198 | 232 1 20    | DMR+ MB 0.95 | MBplus S |       |
| DMR-LIVE                                                                                                             | CONFIG                   | 262400          | DB0NG      | Fri Mar 20 09:15:00 2015 | 217.191.49.246  | 62006        | 438.9000       | 431.3000    | -7.6  | 4006/15 | Link 4006 | 262 1 20    | A5.05.10.007 | RD985 S  |       |
|                                                                                                                      | CONFIG                   | 232192          | OE1XQU     | Fri Mar 20 09:15:00 2015 | 44.143.8.68     | 62006        | 438.4500       | 430.8500    | -7.6  | 4180/15 | Link 4180 | 232 1 20    | A6.05.10.004 | RD985 M  |       |
| USER                                                                                                                 | CONFIG                   | 232605          | OE1XCD     | Fri Mar 20 09:15:00 2015 | 81.217.111.56   | 62006        | 438.9750       | 431.3750    | -7.6  | 4191/15 | Link 4191 | 232 1 20    | A7.00.09.003 | RD985 M  |       |
|                                                                                                                      | CONFIG                   | 232604          | OE1XBF     | Fri Mar 20 09:15:00 2015 | 185.29.89.105   | 62006        | 438.9125       | 431.3125    | -7.6  | 4196/15 | Link 4196 | 232 1 20    | A6.05.10.004 | RD985 M  |       |
| USER+                                                                                                                | CONFIG                   | 232191          | OE1VAK     | Fri Mar 20 09:15:00 2015 | 44.143.9.52     | 62006        | 438.4250       | 430.8250    | -7.6  | 4180/15 | Link 4180 | 232 1 20    | A7.00.09.003 | RD985 M  |       |
|                                                                                                                      | CONFIG                   | 262899          | DB0NA      | Fri Mar 20 09:15:00 2015 | 212.125.105.170 | 62006        | 439.5875       | 431.9875    | -7.6  | 4198/15 | Link 4198 | 20 1        | A6.05.10.004 | RD985 M  |       |
| REF-LIST                                                                                                             | CONFIG                   | 232893          | OE1XNK     | Fri Mar 20 09:15:01 2015 | 44.143.19.50    | 62006        | 438.4250       | 430.8250    | -7.6  | 4191/15 | Link 4191 | 232 1 20    | A7.00.09.003 | RD965 M  |       |
|                                                                                                                      | CONFIG                   | 232391          | OE1XNR     | Fri Mar 20 09:15:01 2015 | 82.218.27.11    | 62006        | 438.4000       | 430.8000    | -7.6  | 4191/15 | Link 4191 | 232 1 20    | A7.00.09.003 | RD625 M  |       |
| REF-LIST+                                                                                                            | CONFIG                   | 232303          | OE1XHB     | Fri Mar 20 09:15:02 2015 | 44.143.9.73     | 62006        | 438.4250       | 430.8250    | -7.6  | 4193/15 | Link 4193 | 232 1 20    | DMR+ MB 0.95 | MBplus S |       |
|                                                                                                                      | CONFIG                   | 232703          | OE1VAK     | Fri Mar 20 09:15:02 2015 | 44.143.9.77     | 62006        | 438.3500       | 430.7500    | -7.6  | 4197/15 | Link 4197 | 232 1 20    | DMR+ MB 0.95 | MBplus S |       |
| MASTER                                                                                                               | CONFIG                   | 232991          | OE1VAK     | Fri Mar 20 09:15:02 2015 | 84.115.117.45   | 62006        | 438.5000       | 430.9000    | -7.6  | 4199/15 | Link 4199 | 232 1 20    | A6.00.05.004 | RD985 S  |       |
|                                                                                                                      | CONFIG                   | 232601          | OE1XAG     | Fri Mar 20 09:15:02 2015 | 44.143.9.71     | 62006        | 438.6000       | 431.0000    | -7.6  | 4196/15 | Link 4196 | 232 1 20    | DMR+ MB 0.95 | MBplus S |       |
|                                                                                                                      | CONFIG                   | 262411          | DF0MHR     | Fri Mar 20 09:15:03 2015 | 91.16.219.64    | 62006        | 439.0375       | 431.4375    | -7.6  | NO SET  | NO-LINK   | 262 1 20 10 | A5.05.10.007 | RD985 S  |       |
|                                                                                                                      | CONFIG                   | 232193          | OE1XQU     | Fri Mar 20 09:15:03 2015 | 44.143.26.50    | 62006        | 145.5875       | 144.9875    | -0.6  | 4191/15 | Link 4191 | 232 1 20    | A6.05.10.004 | RD985 M  |       |
| RepeaterOnline: 17    Voice: GER    EFN:off    SPING: 41.50 ms    Build: 000    Start Time: Fri Mar 20 09:14:57 2015 |                          |                 |            |                          |                 |              |                |             |       |         |           |             |              |          |       |

---

## **questions to the software and the WinMaster (OE-MASTER) in OE**

---

Please EMail an [oe1kbc@oevsv.at](mailto:oe1kbc@oevsv.at)